

# TSTATCCEWF-01 Carrier Smart Thermostat



## Installation Instructions



Designed in the USA.

**NOTE:** Read the entire instruction manual before starting the instructions.



**WARNING:** Contains strong magnets; can be harmful to pacemaker wearers. Magnets are permanently installed; swallowing risk is removed.




# Table of Contents

|  |    |
|--|----|
| Safety Considerations . . . . .  | 4  |
| Introduction. . . . .  | 5  |
| How to Connect in 3 Easy Steps. . . . .                                      | 6  |
| Get to Know Your Carrier Smart Thermostat. . . . .                           | 7  |
| Installation Considerations . . . . .  | 8  |
| Installation . . . . .   | 10 |
| Thermostat Setup with the Service Technician App. . .                        | 16 |
| Manual Setup of Thermostat HVAC Configuration on<br>the Thermostat . . . . . | 17 |
| System Start-Up and Checkout. . . . .  | 22 |
| Operational Information . . . . .  | 23 |
| Troubleshooting . . . . .  | 28 |
| Equipment Configuration Outputs . . . . .                                    | 30 |
| Manual Configuration. . . . .  | 31 |
| Wiring Diagrams. . . . .   | 35 |
| C-Wire Diagrams . . . . .  | 43 |
| Compliance and Certification . . . . .                                       | 44 |

## Safety Considerations

Read and follow manufacturer instructions carefully. Follow all local electrical codes during installation. All wiring must conform to local and national electrical codes. Improper wiring or installation may damage thermostat.

Recognize safety information. This is the safety-alert symbol . When you see this symbol on the equipment and in instruction manual, be alert to the potential for personal injury.

Understand these signal words: **DANGER**, **WARNING**, and **CAUTION**. These words are used with the safety-alert symbol. **DANGER** identifies the most serious hazards which will result in severe personal injury or death. **WARNING** signifies a hazard which could result in personal injury or death. **CAUTION** is used to identify unsafe practices which may result in minor personal injury or product and property damage. **NOTE** is used to highlight suggestions which will result in enhanced installation, reliability, or operation.


### **WARNING**

Contains strong magnets; can be harmful to pacemaker wearers. Magnets are permanently installed; swallowing risk is removed.

# Introduction

The Carrier Smart Thermostat is a 24V Wi-Fi-enabled wall-mounted, low-voltage control. It includes an LED temperature display and 4 capacitive touch buttons to control temperature setpoints and heating/cooling/fan modes of operation from the thermostat.

Homeowners can remotely, via the Carrier SmartHome app, set temperature as well as set daily/weekly programmable schedules with 4 comfort profiles - home/sleep/wake/away. The Smart Thermostat offers a simplistic, smartphone-like feel and easy snap on/snap off removal from the backplate thanks to its patent-pending design.



A250162 Rev. B

## SMART HOME READY

Once Wi-Fi onboarding is complete via the SmartHome app, use your preferred home automation app to scan the Smart Home QR Code on the back of the thermostat housing and add the device. Or use your third party smart home platform to scan the Smart Home QR code.

# How to Connect in 3 Easy Steps

## Contractors

1. Download and open the Carrier Service Technician App from the App Store or Google Play.
2. Launch the App then select Connect to Equipment and then Smart Thermostat.
3. Follow the guided thermostat configuration instructions.\*



## Homeowners


1. Download the Carrier SmartHome App from the App Store or Google Play and create an account.
2. Launch the App then select Add New Device and then Smart Thermostat.
3. Follow the guided setup instructions to connect to your Wi-Fi network.\*



\* When instructed, utilize the mobile onboarding QR code found in one of three locations:

- On the front of this manual
- The hang tag attached to front of thermostat
- Back of the thermostat

# Get to Know Your Carrier Smart Thermostat




# Installation Considerations

## Power

This thermostat is powered by 24VAC only. It requires 24VAC (Rh and/or Rc and C terminals) of the low-voltage transformer to be connected to it for proper operation. It will not operate without these 2 connections.

Rh and Rc are connected via the shunt jumper (see Fig. 1). For applications using two 24VAC transformers, one in the indoor unit and one in the outdoor unit, remove the shunt jumper (Fig. 1). Connect the common from each to the C terminal. Connect R from the indoor unit to the Rh terminal. Connect R from the outdoor unit to the Rc terminal. The W signals are taken from the Rh power and the Y signal is taken from the Rc power. If thermostat has been installed in a two—transformer application that is later changed to a single—transformer installation, installer must install a field supplied jumper between Rc and Rh.



**Fig. 1 – Shunt Jumper**

## **Accessory Output and Connections**

This thermostat is equipped with a dry contact output for the management of humidifiers, dehumidifiers and ventilation equipment. The 2 terminals are both labeled as ACC. The dry contact output must be configured for the management of either one of them.

### **Ventilation (ERV, HRV)**

Function will be activated for the % on time configured, using a cycle rate of 1h. For example, if it is set to 50%, function will be active for the first 30 min and inactive for the next 30 min. If the difference in temperature is larger than the defined max indoor/outdoor temp delta, the function will never activate. If the outdoor temperature is not available, the thermostat will still follow the percent on time, disregarding the max delta parameter.

### **Humidifier**

Control will be based on a setpoint (which will trigger the activation of the function) and a pre-defined hysteresis of 5% above the setpoint. If humidifier with active heat option is selected, the humidifier will only be activated when the heat is running, regardless of the humidifier setpoint.

### **Dehumidifier**

Control will activate the dehumidifier output when the humidity reaches the setpoint and will de-activate the dehumidifier output when the humidity is 5% below the humidity setpoint. If dehumidifier with fan option is selected, the dehumidifier will be activated when the fan is running, and there is a demand for dehumidification, or during a call for cooling.

# Installation



## **UNIT DAMAGE HAZARD**

Failure to follow the recommended wiring practices could result in damage to the wall control and personal property. Improper wiring or installation may damage the thermostat. Check to make sure wiring is correct before proceeding with installation or turning on power.

## **Installation Notes:**

- No part of the thermostat should be installed directly outdoors or in a cabinet outdoors.
- Never remove the thermostat board from the plastic housing. Doing so could warp and damage the components on the board.
- The mounting plate should be mounted to the wall before wires are attached.
- During thermostat installation, provide sufficient excess wiring behind the mounting plate. Coil the wiring, creating a service loop, and place in mounting box or behind the wall to remove strain against the terminal strip.
- For all wiring applications, use 18-22 AWG or larger single-stranded thermostat wire. Continuous wire lengths over 100 ft. (30.5 m) should use 20 AWG or larger. Wire lengths are not to exceed 250 ft. (76 m) per run.

## **Packaging contains the following components:**

1. Thermostat
2. Anchors and screws
3. Warranty card
4. Installation instructions
5. Optional wall plate

## **Thermostat Location**

Thermostat should be mounted:

- Approximately 5 ft (1.5m) from floor.
- Close to or in a frequently used room, preferably on an inside partitioning wall.
- On a section of wall without pipes or duct work.

### **Thermostat should NOT be mounted:**

- Close to a window, on an outside wall, or next to a door leading to the outside.
- Exposed to direct light or heat from a lamp, sun, fireplace, or other temperature-radiating objects which could cause a false reading.
- Close to or in direct airflow from supply registers and return-air registers.
- In areas with poor air circulation, such as behind a door or in an alcove.

## Install Thermostat



### **WARNING**

#### **ELECTRICAL OPERATION HAZARD**

Failure to follow this warning could result in personal injury or death.

Before installing thermostat, turn off all power to equipment. There may be more than 1 power disconnect.



### **CAUTION**

#### **UNIT DAMAGE HAZARD**

Failure to follow this caution may result in equipment damage or improper operation.

Improper wiring or installation may damage thermostat. Check to make sure wiring is correct before proceeding with installation or turning on power.


1. Turn off all power to equipment.
2. If an existing thermostat is being replaced:
  - a. Remove existing thermostat from wall.
  - b. Take photo of existing thermostat wiring before starting new thermostat installation.
  - c. Disconnect wires from existing thermostat, one at a time.  
As each wire is disconnected, record wire color and terminal marking.
  - d. New or additional wires may be needed to accommodate C wire.
  - e. Discard or recycle old thermostat.

# CAUTION

## ENVIRONMENTAL HAZARD

Failure to follow this caution may result in environmental damage. Mercury is a hazardous waste. Federal regulations require that Mercury be disposed of properly.

3. Route wires through large hole in the wall mount. Level wall mount against wall (for aesthetic value only thermostat need not be leveled for proper operation) and mark wall through the two mounting holes (note: you might be able to reuse existing mounting locations).



4. Drill two 3/16-in. mounting holes in wall at the screw hole openings in the wall mount. Thermostat may be mounted to a standard junction box, if desired. Screw

hole openings on the wall mount will align with junction box mounting holes.

5. Secure plastic mounting base to wall with screws and anchors provided. Use 2 screws and 2 anchors provided for a secure attachment. Make sure all wires extend through hole in the wall mount.
6. Adjust length and routing of each wire to reach proper connector block and terminal on wall mount with 1/4-in. (6 mm) extra wire.
7. Match and connect equipment wires to proper terminals of each connector block.
8. Push any excess wire into wall and against mounting base. Seal hole in wall to prevent air leaks. Leaks can affect operation and cause incorrect temperature and/or humidity measurement.



Incorrect Wiring

A260060 A260061



Correct Wiring

9. Reattach thermostat to the wall mount. <sup>A260063</sup> Pogo pins on wall mount will align with hole openings on the back of the thermostat. The thermostat will be held to the wall mount by way of the four magnets on the wall mount, and the four screws on the back of the thermostat.
10. Remove plastic film from front of thermostat.
11. It will take approximately 7 seconds for the thermostat to light up after being powered on.

## **Thermostat Setup with the Service Technician App**

*For ease of Install, use the Service Technician App for full system setup, including HVAC configuration, advanced settings and thermostat testing.*


1. To begin setup of your smart thermostat, open the Carrier Service Technician App on your phone. If you have an existing HVACPartners account, please login. If you do not have an existing account, you may continue as a guest to set up the smart thermostat.
2. On the landing screen of the Service Technician App, select the 'Connect to Equipment' button.
3. Select 'Smart Thermostat' from the list of capable equipment connections to begin the process.
4. Locate the QR code found on the front of your installation guide OR on the hang tag OR back of the thermostat, OR choose I can't find my QR code, to connect via Bluetooth and follow the guided setup instructions to connect to the thermostat and complete the setup process.

## Servicing Dealer Declaration

In the final setup steps, you will have the opportunity to associate the smart thermostat with your dealership.

- Select 'Yes' to declare yourself as the servicing dealer.
- Select 'No' to leave this declaration up to homeowner.

After selecting YES, you will be asked if you want to provide contact information (email address and/or mobile phone number) for the homeowner. This will streamline the onboarding process for them through the homeowner app.



## Manual Setup of Thermostat HVAC Configuration on the Thermostat

1. HVAC configuration can be done via thermostat display.
  - a. Use the Mode button to go back.
  - b. Use the Fan button to select.
  - c. Use Up and Down buttons to cycle through options.
2. Upon first power up display will show F for selecting temperature format.

- a. Use Up and Down buttons to change between F and C.
  - b. Press Fan button to select format.
3. After selecting temperature format display will show L1. At this point you may begin selecting a HVAC system type. Use Up and Down arrows to cycle through different HVAC system and sub-system types. Use Fan button to select your HVAC type and sub-system type. Use Mode button to go back.
- a. Supported HVAC system types are as follows:

### **Standard (L1)**

**Standard supports the following sub-system types:**

- 0 Heat 1 Cool (01)

- 0 Heat 2 Cool (02)

- 1 Heat 0 Cool (10)

- If selected, you will be presented with additional choices to include Fan. Use Up and Down arrows to cycle through the two choices.

- Thermostat controls the fan is represented by F0. Furnace controls the fan is represented by F1. Use Fan button to select.

- 2 Heat 0 Cool (20)

- If selected, you will be presented with additional choices to include Fan. Use Up and Down arrows to cycle through the two choices.

- Thermostat controls the fan is represented by F0. Furnace controls the fan is represented by F1. Use Fan button to select.

•1 Heat 1 Cool (11)

–If selected, you will be presented with additional choices to include Fan. Use Up and Down arrows to cycle through the two choices.

Thermostat controls the fan is represented by F0. Furnace controls the fan is represented by F1. Use Fan button to select.

•2 Heat 1 Cool (21)

–If selected, you will be presented with additional choices to include Fan. Use Up and Down arrows to cycle through the two choices.

Thermostat controls the fan is represented by F0. Furnace controls the fan is represented by F1. Use Fan button to select.

•1 Heat 2 Cool (12)

–If selected, you will be presented with additional choices to include Fan. Use Up and Down arrows to cycle through the two choices.

Thermostat controls the fan is represented by F0. Furnace controls the fan is represented by F1. Use Fan button to select.

•2 Heat 2 Cool (22)

–If selected, you will be presented with additional choices to include Fan. Use Up and Down arrows to cycle through the two choices.

Thermostat controls the fan is represented by F0. Furnace controls the fan is represented by F1. Use Fan button to select.

## Heat Pump (L2).

Heat Pump supports the following sub-system types:

- 1 Stage (10)
  - If selected, you will be presented with additional choices to select if the reversing valve is energized for cool (01) or heat (02). Use Up and Down arrows to cycle through the two choices. Use Fan button to select.
- 1 Stage with Aux (11)
  - If selected, you will be presented with additional choices to select if the reversing valve is energized for cool (01) or heat (02). Use Up and Down arrows to cycle through the two choices. Use Fan button to select.
- 1 Stage with 2 Stage Aux (12)
  - If selected, you will be presented with additional choices to select if the reversing valve is energized for cool (01) or heat (02). Use Up and Down arrows to cycle through the two choices. Use Fan button to select.
- 2 Stage (20)
  - If selected, you will be presented with additional choices to select if the reversing valve is energized for cool (01) or heat (02). Use Up and Down arrows to cycle through the two choices. Use Fan button to select.
- 2 Stage with Aux (21)
  - If selected, you will be presented with additional choices to select if the reversing valve is

energized for cool (01) or heat (02). Use Up and Down arrows to cycle through the two choices. Use Fan button to select.

### **Dual Fuel (L3).**

Dual Fuel supports the following sub-system types:

- 1 Stage HP, 1 Heat (11)
  - If selected, you will be presented with additional choices to select if the reversing valve is energized for cool (01) or heat (02). Use Up and Down arrows to cycle through the two choices. Use Fan button to select.
- 2 Stage HP, 1 Heat (21)
  - If selected, you will be presented with additional choices to select if the reversing valve is energized for cool (01) or heat (02). Use Up and Down arrows to cycle through the two choices. Use Fan button to select.
- 1 Stage HP, 2 Heat (12)
  - If selected, you will be presented with additional choices to select if the reversing valve is energized for cool (01) or heat (02). Use Up and Down arrows to cycle through the two choices. Use Fan button to select.

4. After the last parameter is selected, manual configuration will be done, and current temperature will be shown on the display. The thermostat will default to off, fan auto, and will be ready to use.

## **System Start-Up and Checkout**

The thermostat is designed with a built-in installer test capability, Output Test Mode. This allows for easy operation of equipment without delays or setpoint adjustments to force heating or cooling. To use this feature you must first configure the thermostats HVAC type via Manual Setup of Thermostat HVAC Configuration on the thermostat or via the Service Technician app.

To enable and use installer Output Test Mode take the following steps: (To exit test mode without making a selection, choose S0.)

1. Hold the Mode key for 10 seconds. (Only works if system is configured.).
2. Once Output Test Mode is entered the thermostat will display S0.
3. When in the Output Test Mode:
  - a. Use the Mode button to go back.
  - b. Use the Fan button to select.
  - c. Use Up and Down buttons to cycle through options.
4. Stages or Modes available for test are dependent on the HVAC configuration which has been setup. Only those applicable to the selected HVAC type will be shown. The supported test types are as follows:
  - a. Test Heat Stage 1 (H1)
  - b. Test Heat Stage 2 (H2)

- c. Test Auxiliary Heat Stage 1 (A1)
  - d. Test Auxiliary Heat Stage 2 (A2)
  - e. Test Cool Stage 1 (C1)
  - f. Test Cool Stage 2 (C2)
  - g. Test Fan (F1)
  - h. Stop Testing (S0)
5. Use the Up and Down arrows to cycle through the available types and press Fan to select the type you want to test.
  6. After selection, the test function will override temperature setpoint for 20 min to test heat, cool, auxiliary heat, or fan. Stages or modes not available for the selected configuration will not be shown. Test will end by selecting a new test, selecting stop testing or 20 min timeout. While testing, appropriate mode icon and perimeter lighting will blink until test is finished by any method.

## **Operational Information**

### **User Interface**

The display is a dead front display. All digits, icons, and perimeter lighting will be off unless the proximity sensor is activated, a key is pressed by the user, or unless a heating or cooling call occurs. The first key touch will be ignored if the display was off unless the thermostat had already been woken up by the proximity sensor. Once the display has been woken up the ambient temperature will be shown on the segmented display. The up and down temperature arrows, the applicable mode and fan icons, the Wi-Fi on or off icon and OpenADR (if active) will light up.

### **For a setpoint change:**

When a user toggles the increase or decrease setpoint cap touch, the perimeter lighting will blink once per touch in the appropriate color. After 10 seconds, the perimeter lighting and the rest of LEDs will turn off unless a key is pressed.

## **Timers**

### **Five-Minute Compressor Timeguard**

This timer prevents compressor from starting unless it has been off for at least 5 minutes.

### **Cycle Timer**

To prevent short cycling of the HVAC system, especially in the case where compressors are involved, the number of cycles per hour will be limited. This will be a settable parameter through the HVAC configuration in the App. Heating and cooling cycles will be set independently.

For heating the following minimum run time (MRT) and minimum off time (MOT) defaults will be applied based on the number of cycles per hour:

- Standard Gas – MRT = 7, MOT = 5 (5 Cycles per hour)
- Standard Elec – MRT = 5, MOT = 3 (7.5 Cycles per hour)
- Heat Pump – MRT = 15, MOT = 5 (3 Cycles per hour)

For cooling, the following MRT and MOT defaults will be applied based on the number of cycles:

- AC/HP - MRT = 15, MOT = 5 (3 Cycles per hour)

Cycle rates can be increased or decreased in increments of 0.5 and will be inversely proportional to the MRT and MOT of reference of that system. For example, for a Standard Gas

system if cycle rates is increased to 6, MRT = 5.83, MOT = 4.17.

### **Heat/Cool Setpoints (Desired Temperature)**

A minimum difference of 3°F and maximum of 15°F is enforced between heating and cooling desired temperatures.

### **Service**

When working remotely on the thermostat, please advise the homeowner before starting. The thermostat will display "Sr" while maintenance is being done through the Dealer Portal or Service Tech App.



A250163C

### **Equipment On Indicators**

When the thermostat starts a heating or cooling cycle, the perimeter light will illuminate briefly at the start of the heating or cooling cycle. This could occur in the cooling, heating or auto mode. Blue indicates cooling and orange indicates heating. The perimeter lighting can be turned off in the Smart Home App in the settings screen - perimeter lighting.

When emergency heating (AUX) equipment is on the Emergency Heating icon will illuminate when the display is active. The perimeter lighting will glow orange if heating is

active. This could occur in the heating or auto mode depending on the setpoint.

When fan recirculation is active the fan recirculation icon will illuminate when the display is active. The perimeter lighting will glow green if fan recirculation mode is active and operation mode is inactive.

When OpenADR is active the OpenADR icon will illuminate when the display is active. The perimeter lighting will glow yellow if OpenADR is active.

**NOTE:** If a call is pending but the system is not ready to run due to minimum off time, the corresponding mode icon will blink until it is ready to run at which point it will stay solid on.

### **Fan Circulation Mode**

Fan circulation mode will turn on the fan for 33% of the time using 1hour cycles, which includes the time that the fan is on due to an active heating or cooling call.

### **Schedule and Overrides**

The schedule can be set up for each day of the week independently, with up to 5 different transitions per day using the mobile app.

There is no backup schedule within the physical thermostat. Internet connection/service is required to reestablish the schedule. Local time is not stored in thermostat and therefore the schedule will not be followed upon a power on reset (POR) and will require reconnection to the internet for proper timing. If internet connection is lost but there is no loss of power, thermostat will continue following the schedules even if there could be some drift in the time.

You can override schedule from the thermostat or homeowner app. Schedule will resume after 4 hrs if done through the thermostat unless a different time is set from the app. Overrides can be initiated both through the thermostat and app but duration can only be configured through the app with durations of 1-23 hours, or the option of the override duration to be until the next schedule transition, or a permanent override.

### **Alerts/Notifications**

Only active alerts or notifications will be displayed.

On thermostat Alerts/Notifications:

- WiFi Disconnected - found on the thermostat top right corner.
- Energy Event – Open ADR icon lit on top left corner.
- Auxiliary Heat Running: E\* icon lit on lower left corner.

In App Alerts/Notifications:

- Critical Alerts
- Maintenance Alerts
- System Setting Changes
- Utility Events

# Troubleshooting

## Display Does Not Light Up

If the display doesn't power up after power is applied, check the Rc/Rh and C terminals for 24VAC.

## Connecting Thermostat to Apps

- Update the SmartHome App
- Update the Service Tech App

## Reset

There are 2 different resets available for the thermostat.

- nr - Network reset
- Fr - Factory reset

To perform a reset, follow these steps to ensure proper operation:

1. Press (Fan + mode) keys simultaneously for 10s. This will access the reset menu.
2. Use Arrow Up/Down to select the reset type
  - a. nr - Network reset: Default Wi-Fi, BLE, and Matter only. Maintain HVAC settings.
  - b. Fr - Factory reset: Default all registry setting, Wi-Fi, BLE, and Matter related items.
3. If performing a Network (nr) reset confirm the selection of the reset option with single press of fan button.

4. If performing a Factory reset (Fr) confirm the selection of Factory reset with a double press of fan button.

**NOTE:** Performing any reset option will result in power on reset of the device.

**NOTE:** FR reset returns the thermostat to the original factory condition. Erases all installation and WiFi information. Factory reset will restore all settings and operation to original out of the box settings. This includes WiFi, BLE, and HVAC System type setup. This is recommended when any issues persist after trying other troubleshooting matters.

**NOTE:** Network reset will restore default WiFi and BLE. HVAC settings, including HVAC system type are not changed. This is recommended when having issues connecting via Bluetooth, or when having trouble with WiFi.

**NOTE:** If configuration changes are needed to be made to the Smart Thermostat after the homeowner connects to WiFi, changes can be made through the Connected Portal.

## Equipment Configuration Outputs

| HVAC System / Label Names | Rc | Rh | C | W1/A1 | W2/O | G | Y1 | Y2/A2 |
|---------------------------|----|----|---|-------|------|---|----|-------|
| Standard 1C               | Rc | Rh | C |       |      | G | Y1 |       |
| Standard 2C               | Rc | Rh | C |       |      | G | Y1 | Y2    |
| Standard 1H               | Rc | Rh | C | W1    |      | G |    |       |
| Standard 2H               | Rc | Rh | C | W1    | W2   | G |    |       |
| Standard 1H 1C            | Rc | Rh | C | W1    |      | G | Y1 |       |
| Standard 2H 1C            | Rc | Rh | C | W1    | W2   | G | Y1 |       |
| Standard 1H 2C            | Rc | Rh | C | W1    |      | G | Y1 | Y2    |
| Standard 2H 2C            | Rc | Rh | C | W1    | W2   | G | Y1 | Y2    |
| Heat Pump 1 Stage         | Rc | Rh | C |       | O    | G | Y1 |       |
| Heat Pump 1 Stage w/Aux   | Rc | Rh | C | A1    | O    | G | Y1 |       |
| Heat Pump 1 Stage w/2 Aux | Rc | Rh | C | A1    | O    | G | Y1 | Y2    |
| Heat Pump 2 Stage         | Rc | Rh | C |       | O    | G | Y1 | Y2    |
| Heat Pump 2 Stage w/Aux   | Rc | Rh | C | A1    | O    | G | Y1 | A2    |
| DF 1 Stage HP, 1H         | Rc | Rh | C | A1    | O    | G | Y1 |       |
| DF 2 Stage HP, 1H         | Rc | Rh | C | A1    | O    | G | Y1 | Y2    |
| DF 1 Stage HP, 2H         | Rc | Rh | C | A1    | O    | G | Y1 | A2    |

# Manual Configuration

| HVAC System       | System Shorthand | Step 1 Fahrenheit/ Celsius | Step 2 System Type | Step 3 Stages | Step 4 Fan Choice or Reversing Valve | Step 4 Options   |
|-------------------|------------------|----------------------------|--------------------|---------------|--------------------------------------|--|
| <b>Standard</b>   |                  |                            |                    |               |                                      |  |
| Standard 1C       | 0H/1C            | F / C                      | L1                 | 01            |                                      | N/A  |
| Standard 2C       | 0H/2C            | F / C                      | L1                 | 02            |                                      | N/A  |
| Standard 1H       | 1H/0C            | F / C                      | L1                 | 10            | F0 / F1                              | Thermostat controls the fan is represented by F0. Furnace controls the fan is represented by F1. Use Fan button to select. |
| Standard 2H       | 2H/0C            | F / C                      | L1                 | 20            | F0 / F1                              | Same as above  |
| Standard 1H<br>1C | 1H/1C            | F / C                      | L1                 | 11            | F0 / F1                              | Same as above  |
| Standard 2H<br>1C | 2H/1C            | F / C                      | L1                 | 21            | F0 / F1                              | Same as above  |
| Standard 1H<br>2C | 1H/2C            | F / C                      | L1                 | 12            | F0 / F1                              | Same as above  |
| Standard 2H<br>2C | 2H/2C            | F / C                      | L1                 | 22            | F0 / F1                              | Same as above  |

## Manual Configuration (Continued)

| HVAC System                      | System Shorthand | Step 1 Fahrenheit/ Celsius | Step 2 System Type | Step 3 Stages | Step 4 Fan Choice or Reversing Valve | Step 4 Options  |
|----------------------------------|------------------|----------------------------|--------------------|---------------|--------------------------------------|---|
| <b>Heat Pump</b>                 |                  |                            |                    |               |                                      |   |
| Heat Pump 1 Stage                | 1H/1C with HP    | F / C                      | L2                 | 10            | 01 / 02                              | 01= Reversing valve energized for cool<br>02 = Reversing valve energized for heat |
| Heat Pump 1 Stage w/Aux          | 2H/1C with HP    | F / C                      | L2                 | 11            | 01 / 02                              | Same as above   |
| Heat Pump 1 Stage w/ 2 Stage Aux | 3H/1C with HP    | F / C                      | L2                 | 12            | 01 / 02                              | Same as above   |
| Heat Pump 2 Stage                | 2H/2C with HP    | F / C                      | L2                 | 20            | 01 / 02                              | Same as above   |
| Heat Pump 2 Stage w/Aux          | 3H/2C with HP    | F / C                      | L2                 | 21            | 01 / 02                              | Same as above   |

## Manual Configuration (Continued)


| HVAC System       | System Shorthand         | Step 1 Fahrenheit/ Celsius | Step 2 System Type | Step 3 Stages | Step 4 Fan Choice or Reversing Valve | Step 4 Options  |
|-------------------|--------------------------|----------------------------|--------------------|---------------|--------------------------------------|---|
| <b>Dual Fuel</b>  |                          |                            |                    |               |                                      |   |
| DF 1 Stage HP, 1H | Dual Fuel, 2H/1C with HP | F / C                      | L3                 | 11            | 01 / 02                              | 01= Reversing valve energized for cool<br>02 = Reversing valve energized for heat |
| DF 2 Stage HP, 1H | Dual Fuel, 3H/2C with HP | F / C                      | L3                 | 21            | 01 / 02                              | Same as above   |
| DF 1 Stage HP, 2H | Dual Fuel, 3H/1C with HP | F / C                      | L3                 | 12            | 01 / 02                              | Same as above   |

## **HVAC Terminals (10)**


- a. Rc – 24VAC Power (Cooling for two-transformer system)
- b. Rh – 24VAC Power (Heating for two-transformer system)
- c. C – 24VAC Common
- d. W1/A1 – Heat Stage 1/Auxiliary Heat Stage 1
- e. W2/O – Heat Stage 2/HP Reverse valve
- f. G – Fan
- g. Y1 – Cooling Stage 1/HP Stage 1
- h. Y2/A2 – Cooling Stage 2/HP Stage 2/Auxiliary Heat Stage 2
- i. ACC – Accessory, 1 of the below:
  - Dehumidifier
  - Humidifier
  - Ventilation (ERV, HRV)

# Wiring Diagrams


Standard 1C



Standard 2C




### Standard 1H




Furnace / Fan Coil

### Standard 2H




Furnace / Fan Coil


### Standard 1H/1C




### Standard 2H/1C




### Standard 1H/2C




### Standard 2H/2C




### Heat Pump 1 Stage




### Heat Pump 1 Stage with Aux




### Heat Pump 2 Stage




### Heat Pump 2 Stage with Aux




### Heat Pump 1 Stage with 2 Stage Aux




### Dual Fuel 1 Stage Heat Pump 1H




### Dual Fuel 2 Stage Heat Pump 1H



### Dual Fuel 1 Stage Heat Pump 2H




# C-Wire Diagrams



4 existing wires with C-Wire Adapter to accommodate a thermostat that requires 5 wires

A250223 Rev E



Additional wiring  
For applications needing 1 extra wire

A250304B

# Compliance and Certification

## FCC:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not used in accordance with the instructions, may cause harmful interference to radio communications.

There is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase or decrease the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that which the receiver is connected.
- Consult the place of purchase or an experienced remote control/TV technician for help.
- It is strongly recommended that the TV be plugged into a separate wall outlet.

The user is cautioned that changes and modifications made to this equipment without the approval of the manufacturer could void the user's authority to operate this equipment. This device complies with part 15 of the FCC rules.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**UL Statement:**

- Purpose of control: Room Thermostat
- Pollution Degree 2
- Impulse Voltage: 330V

© 2026 Carrier. All rights reserved.

**Catalog No. TSTATCCEWF-02SI**

**Replaces: TSTATCCEWF-01SI**

Edition Date: 04/26

Manufacturer reserves the right to discontinue, or change at any time, specifications or designs without notice and without obligations.